

Wheel Stop Glue Down

Installation Instructions



To Install:

- Mount directly onto **CONCRETE** surface only
Caution!! Not suitable for use on asphalt. Installing on any surface other than concrete, will void the warranty!
- Make sure concrete surface is clean and dry
Remove all oil, grease, or contaminated concrete. Chip the surface down to sound aggregate. The concrete must be dry and have no standing water. Acid etching surface preparation procedures may result in poor bond and should be avoided. Do not prime or seal concrete surfaces.
- Apply 2-3 oz. of two-part epoxy to each anchor plate
- Set into place
- Allow time to dry per epoxy instructions

Two-Part Epoxy Coverage Chart

(Based on optimal conditions, please use only as a reference)

Glue Down Wheel Stop QTY	Qty Epoxy Needed
0 – 9	1 (2-part quart system)
10 – 18	2 (2-part quart system)
19 – 27	3 (2-part quart system)
28 – 36	4 (2-part quart system)